

IJ-6000 Ink-Jet Transaction Printer

Specification

Addmaster Corporation

Address: 225 East Huntington Drive
Monrovia, CA 91016

Web: www.addmaster.com
Phone: (626) 358-2395
FAX: (626) 358-2784

Document: ij6spec.doc

Revisions: 1.5 January 29, 2003

Notices: Subject to change without notice.
© Copyright 2000-2003, Addmaster Corporation

Table of Contents

1	OVERVIEW AND GENERAL DESCRIPTION	3
1.1	General Description	3
1.2	Configuration Options	3
2	EQUIPMENT SPECIFICATION	4
3	PRINTER FEATURES AND SPECIFICATIONS	5
3.1	Printer Overview	5
3.2	Printer Operating Modes Overview	7
3.3	Printing	7
3.5	Validation Printing	9
4	OPERATOR CONTROLS AND INDICATORS	11
4.1	Operator Controls	11
4.2	Operator Indicators	12
4.3	Printer Self-Test & Verification	12
5	INTERFACING: POWER, COMMUNICATIONS, DIP SWITCHES	13
5.1	Power Connections	13
5.2	Serial Interface	13
5.3	Parallel Interface	13
5.4	Printer Communications Buffering	14
5.5	Hardware Interface Handshaking	14
5.6	DIP Switch Settings	15
6	DATA STREAM & COMMAND SET	16
	Data Stream & Commands: Detail	17
6.1	Resets	18
6.2	Options and Configuration	19
6.3	Printing	20
6.4	Print Media Selection	20
6.5	Fonts & Pitch	21
6.6	Print Modes	22
6.7	Line Spacing	23
6.8	Graphics & Images	24
6.9	Status Indications	27
6.10	Paper Control Commands	28
6.11	External I/O Commands	28
6.12	Miscellaneous Commands	28
6.13	Feature Configuration	30
7	STATUS COMMANDS	31
7.1	Send Printer Status, Immediate.	32
7.2	Send Printer Status, Immediate (Variation)	33
7.3	Send ACK After Processing	34
7.4	Send Feature Status.	35
8	INTERFACING EXAMPLES	38
9	CONTROL CODES AND CHARACTER SET TABLES	41
10	ASSOCIATED FEATURES & OPTIONS	42
10.1	Cutter	42
10.2	Supplies Usage Counters	42
10.3	Cash Drawer Interface	42
11	DOCUMENT REVISION INFORMATION	44

1 Overview and General Description

This document provides the electrical, mechanical, and interface specifications of the IJ-6000-L Ink-Jet Printer mechanism.

1.1 General Description

The IJ-6000 Printers are a series of Ink-Jet Transaction Printers for use in a wide variety of applications, including: Banking and Point-of-Sale. The IJ-6000 has several available options, including validation mechanisms, cutters, and interface emulations.

Special features include: plain-paper printing, validation, quiet operation, high resolution and high speed printing, and a choice of interfaces and power connections.

This printer utilizes the Hewlett-Packard C6602A ink-jet printhead. This printhead prints at 144 by 96 dpi using 12 nozzles.

1.2 Configuration Options

The IJ-6000 can be factory configured in a variety of ways. The printer will be configured at the time of manufacture and the is not user-modifiable. This specification addresses each of the configurable options, although they may not be applicable for every unit.

<i>Items:</i>	<i>Configurations Available</i>
Power Connector:	Switchcraft 722A
Interface:	Serial, RS232C Parallel, (Centronics type)
Options:	Paper cutter Validation mechanism Interface emulations Cash Drawer interface 2 nd Serial Port (to be implemented)

2 Equipment Specification

Item	Specification
Power Requirements	
<i>Voltage</i>	24 Volts DC (+/- 10%) (Standard)
<i>Power Consumption</i>	
<i>Operating</i>	14 Watts Maximum
<i>Standby</i>	2 Watts
Operating Environment	
<i>Temperature</i>	10 -> 40 C
<i>Humidity</i>	10 -> 90% RH (non-condensing)
Printer Engine	
<i>Type</i>	Thermal Ink Jet
<i>Ink Cartridge</i>	Hewlett-Packard C6602A
<i>Ink Detection</i>	Ink drop usage counter.
<i>Resolution</i>	144 x 96 DPI (horizontal x vertical)
<i>Modes</i>	Standard and Ink-Saver (draft quality mode)
<i>Speed</i>	280 characters/sec. Max. (standard font)
Print Media / Paper	
<i>Type</i>	Roll, Plain Paper
<i>Size</i>	3 Inch Wide 3 Inch Diameter (Maximum) 5/8 Inch Core I.D. (Typical, but not req'd.)
<i>Paper Detection</i>	Paper-Out. Mechanical arm w/photo sensor. Form Inserted. Reflective photo sensor.
<i>Paper-Usage</i>	Electronic counter.
Paper Handling	
<i>Loading</i>	External loading with smart feed.
Communications	
<i>Data Buffer</i>	4K (32K RAM standard)
<i>Interfaces</i>	RS-232C (standard) Parallel (optional)
Physical Characteristics	
<i>Dimensions</i>	6.5" (W) by 3.25" (H) by 6.25" (D)
<i>Weight</i>	4.6 lb.
<i>Noise Level</i>	48 DBA at t.b.d. feet

3 Printer Features and Specifications

3.1 Printer Overview

Printer Features	
Logical Unit	
<i>Processor</i>	Intel 80C251
<i>RAM</i>	32K
<i>Firmware Storage</i>	128K Flash, with download procedure
<i>Variables Storage</i>	1K bit EEPROM
Characters & Fonts	
<i>Character Height</i>	0.070 to 0.125 inch (font dependent)
<i>Character Set</i>	Code page 850 (page 437 optional)
<i>Fonts:</i>	5 Printer Fonts in Flash Memory <ul style="list-style-type: none"> -Standard -Large -Large Bold -Times Roman -OCR-A -BarCodes: Code 39, 93, 128, I2of5
<i>Font Storage</i>	Flash Memory: 64K Bytes for Fonts
<i>Font Configurability</i>	Downloadable procedure available.
<i>Printing Modes:</i>	3 Modes: non-exclusive <ul style="list-style-type: none"> -Double-Wide / Single-Wide -Uni-directional / Bi-directional -Upside-Down / Rightside-Up
Supplies: Features & Specifications	
Printhead & Ink	
<i>Print Head</i>	Hewlett-Packard C6602A
<i>Ink Cartridge Life</i>	5,000,000 characters, standard font
<i>Print Contrast Ratio</i>	Constant throughout life of cartridge.
Paper Media	
<i>Media Type</i>	Roll Paper
<i>Recommended Stock</i>	Rittenhouse #7055SB
<i>Roll Diameter</i>	3.0 inches maximum
<i>Roll Core I.D.</i>	5/8 inches typical, (no special requirement)
<i>Thickness</i>	0.0015 to 0.03 inches
<i>Width</i>	3.00 inches (+0.1/-0.1)

Printer Capabilities and Capacities

Printer Speed

<i>Print Speed</i>	280 char/sec Max. (standard font)
<i>Print Throughput</i>	4.5 lines/sec. (continuous text printing 42 char/line, 6 lines/inch)
<i>Paper Feed Speed</i>	7 inches/sec.
<i>"Typical" Receipt Throughput</i>	1.2 inches/sec.

Printer Resolutions

<i>Resolution (native)</i>	144 x 96 dpi (horizontal x vertical)
<i>Resolution (addressable)</i>	144 x 96

Validation Capacity

<i>Print Zone (Lines)</i>	8 lines at 6 lines/inch
<i>Print Zone</i>	2.67 inches wide, by 1.54 inches tall see definitions for details

3.2 Printer Operating Modes Overview

<i>Category</i>	<i>Mode</i>	<i>Sub-Modes</i>	<i>Unit is:</i>
<i>Operation</i>	Operating	On-Line	Operational -- may be utilized.
		Off-Line	On-Line. Host may send data. Off-Line. Host should not send data.
	Download	Firmware download procedure underway.	
	Self-Test		Self-test procedure underway.
<i>Printing</i>	Journal		Data printed to journal.
	Multi-LineValidation		Form validation procedure.
	Ink-Saver		Unit prints in draft quality conserving ink supply.
	Regular Ink		Standard printing.

3.3 Printing

Printing Overview:

Printing is accomplished by sending print data to printer and commanding a vertical motion to the print-head. Printing occurs in other cases also, but these are the exception.

The printer includes various sensors to assure that printing occurs only on the media previously selected by the Host. For example, if Journal printing is selected, the printer will halt if a form is inserted erroneously. The printer will automatically restart when any blocking condition is cleared.

Printing will not take place if the unit is Off-Line or is out of paper. Both of these conditions are noted by operator indicators.

In absence of Host commands, the printer will use its default settings, which are:

<i>Item</i>	<i>Default Setting</i>
<i>Font</i>	Standard
<i>Line Spacing</i>	Right-side Up
<i>Ink-Saver</i>	6 lines / inch
<i>Media</i>	Not supported at this time.
<i>Method</i>	Journal Media
	Bi-directional printing

Font Overview:

The printer includes 5 internal fonts and 3 bar codes, which are given in the following table.

<i>Name</i>	<i>Pitch Char/Inch</i>	<i>Capacity Journal</i>	<i>Char/Line Validation</i>
<i>Fonts:</i>			
<i>Standard</i>	16	42	42
<i>Large</i>	12	32	32
<i>Large Bold</i>	12	32	32
<i>Roman</i>	Proportionally spaced	~30	~30
<i>OCR-A</i>		16	16
<i>Bar Codes:</i>			
<i>Code-39</i>		12	12
<i>Code-128</i>		12	12
<i>Inter. 2 of 5</i>		12	12
<i>UPC-A</i>		12	12

Fonts may be mixed within a print line. If so, then the available number of characters per line will depend upon the mixture of fonts. If the print line is longer than the available media width, the print line will be truncated (no wrap-around).

Fonts are downloadable into the printer non-volatile Flash memory by a procedure described in the document "*IJ-6000 Flash Programming Guide*." Contact the factory if interested.

Barcodes may not be mixed with fonts or other barcodes on the same line. Barcodes print automatically centered in the printfield and are 3/8 inches tall. Barcodes are printed uni-directionally at half-speed.

Ink-Saver Mode:

Not supported at this time.

3.5 Validation Printing

Validation of Forms:

For the IJ-6000, there is only one method for validation. It is called *Multi-Line Validation Mode*. On other printer models, other methods (modes) of validation may be possible. We use the full term here to prepare for that case in future specifications.

The IJ-6000 validates by clamping the cut-form, moving the print-head horizontally during printing, and feeding the cut-form vertically to ready it for the next line of print.

Validation Mode is entered by sending a software command to the printer. Validation Mode remains in effect indefinitely and only exits by sending another software command. Consult Section 7 for the exact command syntax.

The Validation Mode pertains to 1 (one) document only. The printer follows these steps in validating forms. *Each* step must be undertaken for *each* document validated.

	<i>Multi-Line Validation Procedure</i>	<i>Via</i>	<i>Form LED</i>
1.	Printer enters Validation Mode.	Software cmd.	On
2.	Printer waits for Form to be inserted.		On
3.	Printer prints on Form.	Software cmd.	Off
4.	Printer replaces Form and waits for Form to be removed.	Software cmd. or excess data	Flashing
5.	Printer exits Validation Mode.	Software cmd.	Off

The following notes are important:

- If the capacity is exceeded (more than 8 lines sent), then any excess print data causes the following:
 - subsequent print data is ignored,
 - the form is returned to its original position and the clamp is opened,
 - operation will not continue until the Form is completely removed from the printer.
- *The printer remains in Validation mode until this mode is quit via a software command.*
- If the cut-form is removed during Multi-Line Validation, the printing mechanism will stop and abort the printing. It does this to prevent ink from being ejected into the printer.
- After Multi-Line Validation is completed, the cut-form is returned to its original position and the clamp is opened to allow for removal of the cut-form.
- The paper-feed button is operational during Multi-Line Validation.

Document Media and Validation Capacity Specification:

<i>Category</i>	<i>Item</i>	<i>Specification</i>
Document Media		
	<i>Document Thickness</i>	0.0015 to 0.0180 inches
	<i>Document Capacity:</i>	
	<i>Loading</i>	1 form, 0.018" max
	<i>Catch Chute</i>	none
	<i>Document Width</i>	
	<i>Minimum</i>	5.5 inches
	<i>Maximum</i>	unlimited
Validation Printing		
	<i>Lines</i>	8 max. at 6 lines/inch
	<i>Print Zone: 1st Line</i>	1.35 inches, baseline to form bottom
	<i>Print Zone: Last Line</i>	0.25 inches baseline to form bottom
	<i>Print Zone: Width</i>	2.67 inches

4 Operator Controls and Indicators

4.1 Operator Controls

The operator controls are clearly marked. Only three are present in this model, and their usage is given in the following table.

<i>Item</i>	<i>Usage</i>
<i>Power Switch.</i>	<p><i>Power Switch.</i></p> <p>Cuts power to the printer</p> <p>Located: Mid-Left side at bottom.</p>
<i>Paper-Feed Button.</i>	<p><i>Smart Paper-Feed.</i></p> <p>Feeds paper forwards:</p> <p>Short depression: causes unit to automatically load paper into mechanism.</p> <p>Long depression: will feed paper while button is depressed. Waits ½ second before beginning to feed.</p> <p>Located: Top, rear, right side.</p>
<i>On-Line Button.</i>	<p><i>On-Line and Off-Line toggle.</i></p> <p>Toggles unit between the two modes. When unit is Off-Line, printing and communications are inhibited.</p> <p>Located: Top, rear, right side.</p>

4.2 Operator Indicators

The operator indicators are LED lights which are located on the top front of the unit. They are identified by markings and colors. Their usage is given in the following table.

<i>Indicator</i>	<i>State</i>	<i>Meaning</i>
<i>On-Line LED.</i>	ON	Power is ON. Printer is On-Line and ready to operate.
	FLASH	Printer is Off-Line. Flashing is very low rate.
	OFF	Power is OFF.
<i>Status LED.</i>	ON	Error or Out-Of-Paper.
	OFF	No errors.
<i>Form LED.</i>	ON	Insert form for validation.
	FLASH	Remove form from printer.
	OFF	No form attention required.

4.3 Printer Self-Test & Verification

The printer includes a **Self-Test Routine**. This routine tests the following features:

- Identification: Model Number, Firmware & Revision Level, Installed Options
- Operation: Printing, Feeding, Cutting, Validation Clamping & Ejecting,
- Printing: All fonts and print modes.

To perform test, follow these steps:

Self-Test Procedure	Notes
1. Turn off power	
2. Hold down Paper-Feed button	
3. Turn on power	
4. Release button after printing starts	
5. A sample tape is printed	
6. Insert Form to test validation mechanism (if present)	
7. Turn power off when done.	

IMPORTANT NOTE:

Printer remains in SELF-TEST routine until power is cycled OFF.

5 Interfacing: Power, Communications, DIP Switches

5.1 Power Connections

Please use only the factory supplied power supply. If using another supply, please contact factory for proper power connections.

5.2 Serial Interface

Baud Rates:	9600 or 38400 (DIP switch selectable)
Data Bits:	8, w/1 stop bit
Parity:	None.
Handshaking:	Printer toggles RTS, which is connected by standard cables to IBM PC's CTS signal.
Interface Connector:	RJ-45 (phonejack type connector) RS232C interface levels.
Pin Configurations:	Standard PC compatible 9 pin. Mates directly to PC.
Cabling:	Addmaster P/N: 95078 Printer to PC compatible DB9 type serial port Cable is 8 conductor RJ-45 to DB9 pin female.

5.3 Parallel Interface

Interface Connector:	25 pin, male, 'DB-25' type connector. TTL interface levels.
Pin Configurations:	Standard PC compatible assignments.
Cabling:	Addmaster P/N: 95529 Printer to PC compatible DB25 type parallel port Cable is 25 conductor male to female straight through.

5.4 Printer Communications Buffering

The printer has two type of buffers into which it places incoming characters:

Receive Buffer:

Stores incoming characters. The printer removes characters from the Receive Buffer when needed. The characters are then “processed.”

The Receive Buffer, stores 4096 characters. In some models, this buffer may be larger.

Print-Line Buffer:

Stores characters (typically text characters) after processing, but before actual printing. This buffer is used to build up the complete “Print-Line” that will then be printed or validated.

In the standard IJ-6000, the Print-Line Buffer is approximately 96 characters. Therefore, you can not print a line with more than 96 characters (including any formatting commands).

5.5 Hardware Interface Handshaking

When the Receive Buffer is full or is otherwise unavailable, then the printer is unable to receive any characters. If any are sent, then they will be lost. This “un-availability” is signaled to the computer by “handshaking” lines on the interface.

For the Serial Interface:

The printer toggles its RTS line which is connect through the standard cables to the computer's line called “CTS”. If the computer tests CTS high, then data can be sent, and if tested low, then do not send data. This testing is usually accomplished automatically via the computer's BIOS routines. CTS goes low when the Receive Buffer reaches 256 characters from full.

For DOS based computers, set the “mode” command as indicated below. The “p” parameter sets the appropriate retry on the CTS line when used with printers in general.

```
C:> mode com1:9600,n,8,1,p
```

For Windows 95/98/NT based computers, check the settings for the appropriated COM port. Assure that *Flow Control* is set to *Hardware*.

For the Parallel Interface:

The printer signals that it is busy by holding the line called “BUSY” high. No characters may be sent when BUSY is high.

5.6 DIP Switch Settings

DIP Switches set functional features of the IJ-6000. The Switches are accessible from the bottom of the unit.

<i>DIP Switch</i>	<i>Setting</i>	<i>Usage</i>
1	ON OFF	Firmware Download Mode Printing Mode
2	ON OFF	Reserved
3	ON OFF	38400 Baud 9600 Baud
4	ON OFF	Auto-LF on CR Enabled Auto-LF on CR Disabled

Notes:

- Defaults are all OFF.
- For Parallel Units, DIP Switch 3 is not used.
- Firmware Download Mode is described in another document.
- DIP 2 is reserved for ink-saver mode. To be implemented.
- Auto-LF on *CR* usage is described in Section 6 under the *CR* command.

6 Data Stream & Command Set

An overview of the supported interface commands is given below.

<i>Type</i>	<i>Sequence</i>	<i>Function</i>
RESETS		
	<i>CAN</i>	Reset. Hard power-on reset, at receive level.
	<i>ESC @</i>	Initialize. Soft, at process level.
	<i>STX</i>	Clear Print-Line Buffer.
OPTIONS		
	<i>ESC > n</i>	Set print mode options. <i>n</i> is bit-mapped.
	<i>SOH</i>	Set printer initialized bit. <i>PINIT</i> .
PRINTING		
	<i>LF</i>	Line Feed. Print and feed.
	<i>CR</i>	Carriage Return. Print and no-feed.
PRINT MEDIA SELECTION		
	<i>ETB</i>	Enter <i>Multi-Line Validation</i> Mode.
	<i>FF</i>	Exit <i>Multi-Line Validation</i> Mode and eject Form.
FONTS & PITCH		
	<i>ESC 2 n</i>	Set print font. <i>n</i> is bit-mapped. See table
	<i>SO</i>	Selects Single-Wide pitch (cancels Double-Wide)
	<i>SI</i>	Selects Double-Wide pitch.
	<i>GS</i>	Selects Large Font.
	<i>FS</i>	Selects Large Bold Font.
	<i>RS</i>	Selects Standard Font.
	<i>US</i>	Selects Standard Bold Font.
PRINT MODES		
	<i>SUB</i>	Set "Upside-Down Mode" printing.
	<i>EM</i>	Reset "Upside-Down Mode" printing.
	<i>ESC U</i>	Select Unidirectional Print.
	<i>ESC u</i>	Select Bidirectional Print.
LINE SPACING		
	<i>ESC : n</i>	Set line feed amount to <i>n</i> /300 inches.
GRAPHICS & IMAGES		
	<i>ESC # mn data</i>	Print graphics bit image, 300 DPI.
	<i>ESC \$ mn data</i>	Print graphics bit image, 150 DPI.
	<i>ESC 5 n</i>	Select barcode symbology
	<i>ESC % ...</i>	Print barcode

<i>Type</i>	<i>Sequence</i>	<i>Function</i>
STATUS INDICATIONS		
	<i>ENQ</i>	Send printer status, immediate.
	<i>ESC ? n</i>	Send feature status. <i>n</i> =feature number
	<i>ESC ACK</i>	Send ACK after processing.
PAPER CONTROL		
	<i>VT</i>	Paper Feed forwards past tear bar
CONTROLS AND EXTENSIONS		
	<i>SYN</i>	Turn on LED #1.
	<i>ESC O</i>	Move print-head to docking station.
	<i>ESC P</i>	Move print-head to loading zone.
	<i>ESC V</i>	Enter Power Down state.
	<i>ESC 1 n</i>	Adjust Right/Left Alignment.
	<i>ESC t</i>	Select fast clamp timing on Validation.
	<i>ESC r</i>	Select standard speed clamp timing on Validation.
	<i>ESC 0xf0 ... ESC 0xff</i>	Factory Debugging Commands. Do not use.
FEATURE CONFIGURATION		
	<i>ESC = n</i>	Set feature value to <i>n</i> .

Data Stream & Commands: Detail

Detail on each of the supported commands follows in this section. The commands are grouped according to function. A table listing the Hex and Decimal values of each of the codes is given in Section 9.

6.1 Resets

<i>CAN</i>	Reset. Hard reset, at receive level.
------------	--------------------------------------

This command will clear out the Receive Buffer, reset any modes, fonts, and other settings to the default values, and re-initialize the interface.

This command basically emulates a Power-On Reset. It is acted upon as soon as it is received, even if the Receive Buffer contains unprocessed data. Use this command only when needed -- at Host driver power on, error condition clearing, etc.

This command also resets the Printer Initialized bit (*PINIT*).

See also the *ESC @* command.

Syntax: 18H

<i>ESC @</i>	Initialize. Soft, at process level.
--------------	-------------------------------------

This command will clear out any partially formed print-line, reset any modes, fonts, and other settings to the default values.

This command basically emulates a Soft Reset. It is acted upon removed from the Receive Buffer (after all previous commands received have been processed).

Does not affect Receive Buffer! Does not affect *PINIT* bit.

This command is typically used ONCE at the start of each print-job to put the printer into a known state concerning fonts, print-modes, etc

Syntax: 1BH 40H

<i>STX</i>	Clear print line buffer and FORM LED.
------------	---------------------------------------

Soft reset, at process level. This command will clear out any partially formed print-line. Also will turn off FORM LED.

Does not affect Receive Buffer!

Syntax: 02H

6.2 Options and Configuration

ESC > n Set print mode options. *n* is bit mapped.

This command sets or clear various operational options. Each option is set or cleared depending on parameter *n* which is interpreted in a bit-mapped manner. Consult the following table.

<i>Bit</i>	<i>Setting</i>	<i>Usage</i>
0 (lsb)	0	Fonts reset after each printed line
	1	Fonts stay set until changed
1	0	Reserved, use 0
2	0	"
3	0	"
4	0	<i>ENQ</i> returns short response
	1	<i>ENQ</i> returns long response
5-7	0	Reserved, use 0

This option byte is defaulted to 0. It is reset on Power-On, or by the *CAN* or *ESC @* commands.

Always write 0's to reserved bits to insure compatibility with future upgrades and features.

Syntax: 1BH 3EH *n*

SOH Set printer initialized bit *PINIT*.

Sets *PINIT* to 1. *PINIT* is reset to 0 by: Power On or *CAN* command.

Printer initialized bit *PINIT* can be read by the *ENQ* command. *PINIT* can be used by the host to determine whether the printer was reset by power failure or operator.

Syntax: 01H

6.3 Printing

LF Line Feed. Print and line feed 1 line.

Any data previously received is printed. The paper is feed an amount specified by the current line spacing value.

Syntax: 0AH

CR Carriage Return. Print and no line feed.

Any data previously received is printed. The paper is not fed in typical usage. If Auto-LF on CR mode is set by DIP switch, then the paper is fed 1 line.

Syntax: 0DH

6.4 Print Media Selection

ETB Enter *Multi-Line Validation* mode.

Printer enters Multi-Line Validation Mode. Form LED is illuminated and printer awaits Form to be inserted before proceeding. If the printer is already in validation mode, the command is ignored.

Syntax: 17H

FF Exit *Multi-Line Validation* mode and eject Form.

Any data previously received is first printed.

Subsequently, if the printer includes the validation mechanism AND the printer is currently in validation mode, then:

- The FORM is replaced into its original position,
- Printer waits until FORM is removed, and while so, Flashes the FORM LED,
- After FORM is removed, returns the printer to Journal printing mode.

Syntax: 0CH

6.5 Fonts & Pitch

ESC 2 n Set print mode/fonts.

The Font and Pitch selected for printing is determined by the value of *n*, which is bit-mapped as shown in the following table:

<i>n</i>	<i>Font Selected</i>
00H	Standard Font
02H	Large Bold Font.
03H	Standard Bold Font
04H	Large Font.
07H	Roman (Proportionally spaced.)
09H	OCR-A
40H	Single Wide Mode ON
41H	Double Wide Mode ON
50H	Ink-Saver Mode OFF (not implement yet)
51H	Ink-Saver Mode ON
others	Reserved.

Fonts may be changed in the middle of a line. Fonts will retain their values across lines depending upon the option setting.

Standard Font is the default.

Syntax: 1BH 32H *n*

<i>GS</i>	Selects Large Font.
<i>FS</i>	Selects Large Bold Font.
<i>US</i>	Selects Standard Bold Font.
<i>RS</i>	Selects Standard Font.

These command produce the same results as the *ESC 2 n* command.

Syntax: 1DH = (GS), 1CH = (FS), 1EH = (RS), 1FH = (US)

<i>SO</i>	Selects Single Wide pitch
<i>SI</i>	Selects Double Wide pitch.

Selects or De-selection double-wide printing. Double-wide printing will resets to single-side at the end of each line as specified by the *ESC >* command.

Syntax: 0EH (SO) 0FH (SI)

6.6 Print Modes

<i>SUB</i>	Set "Upside Down Mode" printing.
<i>EM</i>	Reset "Upside Down Mode" printing.

These modes stay in effect until reset by this command or the *CAN* or *ESC @* commands.

The default is rightside up printing.

Syntax: 1AH (sub)
 19H (em)

<i>ESC U</i>	Select Unidirectional Print.
<i>ESC u</i>	Reset Unidirectional Print. (Bidirectional).

Use these commands to select/reset unidirectional printing. Unidirectional printing enhances the line-to-line registration, however, print speed is reduced by half. Use this mode only if required.

Default is bi-directional printing.

Syntax: 1BH 55H (unidirectional)
 1BH 75H (bi-directional)

6.7 Line Spacing

ESC : *n* Set line feed amount to $n/96$ inches.

Set line spacing to $96/n$ lines per inch.

The default is $n=16$ or 6 lines per inch.

Valid range for n is 1 to 255.

Note that the actual spacing will not be precisely as specified because the printer's feed increment is different from $1/96$ inch.

Syntax: 1BH 3AH *n*

ESC 5 *n* Select barcode symbology

Sets the type of barcode to be printed by subsequent barcode print commands. *n* specifies the barcode type. See table.

<i>n</i>	Barcode selected
00H	Code-128
01H	Interleaved 2 of 5 (I-2/5)
02H	UPC-A
03H	Code-39
others	Reserved.

Syntax: 1BH 35H *n*

ESC % *nm data* Print barcode

Prints a barcode using the currently selected barcode symbology. Data of barcode is supplied with the command.

Barcode is printed approximately in the middle of the print-field and text cannot be printed on the same line. The height of the barcode is approximately 1/3 inch.

The print density of barcodes is not affected by Ink-Saver Mode. Bar codes are always printed uni-directionally at 1/4 full print speed.

n, *m* specify the length in bytes of the following string of *data*. *n* is the least significant byte and *m* is the most significant byte. The format of *data* depends on the type of barcode printed. Examples are presented assuming symbology already selected with the *ESC 5* command:

Syntax: 1BH 25H *n m data*

Examples and Additional Information:

Code-128 Type C:

- Only Type C is fully supported. Type C encodes pairs of characters into one symbol.
- Consult Code-128 Specification for more information.

Example: Print "ABCD", Required Start character is 69H for type-C

1BH 25H 05H 00H 69H 21H 22H 23H 24H

Interleaved 2 of 5:

- Number of data digits must be even.
- Start character is 64H and must be provided by the user.

Example: Print "81562153"

1BH 25H 09H 00H 64H 38H 31H 34H 36H 32H 31H 35H 33H

UPC-A:

- Number of digits must be exactly 11.
- The eleventh digit is a checksum. If provided incorrectly, the printer will correct and print the proper checksum.

Example: Print "07364002107"

1BH 25H 0BH 00H 30H 37H 33H 36H 34H 30H 30H 32H 31H 30H 37H

Code-39:

- Printer adds start/stop characters automatically

Example: Print "123456",

1BH 25H 0BH 00H 31H 32H 33H 34H 35H 36H

6.9 Status Indications

ENQ Send Printer Status, immediate.

See following section for more details on this command and its responses.

The printer will respond to this command immediately after receiving it. Command is operational only for units with the serial interface.

Syntax: 05H

ESC ACK Send ACK.

An *ACK* character (1 byte) is returned to the host after the sequence is processed. This can be used to determine when a print job is complete. To do so, send all print data and afterwards send the *ESC ACK* sequence. When the *ACK* is returned, then all data has been printed.

This command is operational only for units with the serial interface.

Syntax: 1BH 06H

ESC ? n Send Feature Status.

Returns Feature specific information to the host.

n specifies the feature. See table.

<i>n</i>	Feature Status Requested
00H or 02H	Send Mechanism Status
10H ... 1FH	Read Counter #0 (through #15).
20H ... 2FH	Reset Counter #0 (through #15).
30H	Send Model ID String
32H	Send Firmware Version Number String
40H ... 6FH	Read Configuration Byte #0 (through #47). See Configuration Byte Table.
others	Reserved.

See following section for more details on this command and its responses.

The printer will respond to this command after the sequence is processed from the receive buffer. This command is operational only for units with the serial interface.

Syntax: 1BH 3FH *n*

6.10 Paper Control Commands

<i>VT</i>	Feed Paper Forwards to Tear-Bar.
-----------	----------------------------------

Feeds last printline past cut position. After printing a receipt, use the *VT* command to feed the last line through cutter or tear-bar.

Alternately, you can insert approximately 12 lines of text at 6 LPI, to perform almost the same function.

Syntax: 0BH

6.11 External I/O Commands

<i>SYN</i>	Turn FORM LED ON.
------------	-------------------

The LED will remain ON until turned OFF by the *STX* command. The Form LED may toggle during printing. This may change in the future.

Syntax: 16H

6.12 Miscellaneous Commands

<i>ESC O</i>	Move print head to docking station.
--------------	-------------------------------------

Print-head will be moved to docking station. Perform this command before killing power to unit to insure Ink-Jet cartridge is properly docked.

This command is NOT NEEDED in typical operation provided the operator uses the printers Power Switch.

Syntax: 1BH 4FH

<i>ESC V</i>	Enter Power down/Sleep Mode.
--------------	------------------------------

Print-head is docked and capped. All LED's (except power) are turned off, buttons and interface commands are ignored.

The printer stays in sleeps mode until: (1) power is turned off, or (2) the *CAN* command is received. The *CAN* command will emulate a hardware Power-On reset.

Syntax: 1BH 56H

ESC 1 n Adjust Right/Left Alignment

The Right/Left Alignment adjustment value is changed to *n* dots for the currently selected print station. For example, if currently printing to the Journal, only Journal alignment is affected. To change Validation alignment, enter Validation mode first.

This DOES NOT affect the value store in Non-Volatile memory, NOR the value reported back to the host via the "ESC ?n" command.

The setting remains valid until any reset or power on/off sequence.

This value is used for purposes of 1) special effects, 2) testing out various values before making a final selection, 3) future uses.

Syntax: 1BH 31H *n*

ESC r Select Regular speed clamp timing for Validation.

ESC t Select Fast speed clamp timing for Validation

When validation is selected, the Form LED is illuminated and the printer awaits a form to be inserted. After the printer detects the form, it was a small period of time before clamping and printing to allow the operator to release the document. This time period is nominally around 1 second. For applications where this time is too long, use the *ESC t* command to reduce the time period to 0.25 sec.

This command was added June 2002, and will not appear in older machines.

Syntax: 1BH 72H (Regular clamp speed)

 1BH 74H (Fast clamp speed)

Default: Regular clamp speed.

ESC 0xf0 Debugging Commands.

...

ESC 0xff

ESC 0xf0 through ESC 0xff are reserved for factory debugging usage. Do not use any of these commands as they are NOT SUPPORTED for any other purposes.

Syntax: 1BH F0H through 1BH FFH

6.13 Feature Configuration

ESC = n Set feature value to *n*.

Features are selected by number and read-back by the *ESC ? n* command. The last *Feature Number* is saved. Subsequent to sending the *ESC ? n* command, the user can change the value for some of the features by sending the *ESC = n* command. For the *ESC = n* command, *n* will specify the new value to be stored for the previously selected Feature Number.

These commands are used to set various values and calibrations.

Syntax: 1BH 3DH *n*

7 Status Commands

This section gives more detail on the status commands are used to retrieve information from the printer. Three commands are available.

<i>Command</i>	<i>Usage</i>	<i>Response</i>
<i>ENQ</i>	Send printer status.	Immediate
<i>ESC ? n</i>	Send feature status.	Processed
<i>ESC ACK</i>	Send ACK after processing.	Processed

These commands generate responses of two types: Immediate and Processed.

- *Immediate* responses are sent to the host immediately after receiving the request. This response will occur regardless of the state of operation and any pending commands or data.
- *Processed* responses are sent to the host when the command is removed from the Receive Buffer. All prior and pending data and commands are processed before the response is sent.

Thus, there is an indeterminate delay between the Host sending Processed Response status requests and the Host receiving an answer back. Most often the delay will be a few milliseconds, but it can be seconds long. For example, a print job is sent and followed by the *ESC ACK* command. The printer will respond to the *ESC ACK* command after the print job is complete, which may take many seconds or even be delayed indefinitely if the printer is out of paper.

7.1 Send Printer Status, Immediate.

Host Sends: ENQ - 05H
 Printer Response: 1 byte
 Response Type: Immediate.

Usage Details:

The printer responds to this command immediately after receiving it. The printer will respond regardless of its current state of operation. The response to the ENQ command will be 1 byte in length. This is called the Short Response, respectively. This command has a variation which will generate a Long Response. See the next section.

Response Format Bit-map:

Bit	Name	Usage & Meaning	
7	PWRDWN	=1	• power down state
		=0	• operational state
6	BEMP	=1	• if the Receive Buffer is empty and has processed all received data (processed data may not yet have been printed),
		=0	• if Receive Buffer has any unprocessed data.
5	TREMP	=1	Undefined for this model
		=0	
4	PINIT	=1	Used by the host to determine whether the printer was reset by power failure.
		=0	
3	ERROR	=1	• error during validation
		=0	• no error detected or error condition cleared
2	VMP	=1	Used to determine if machine is process of performing a mechanical task that may take an indeterminate amount of time
		=0	• if a valid message has been received and machine is performing an action or printing a line. • otherwise.
1	PRDY	=1	Used to determine if printer can print
		=0	
0	FORM	=1	Used to determine if Form is inserted into Validation Mechanism
		=0	• FORM is detected • no FORM detected

7.2 Send Printer Status, Immediate (Variation)

Host Sends: ENQ
 Printer Response: 4 bytes.
 Response Type: Immediate response.

Usage Details:

This command is a variation on the ENQ command given in the previous section in that the length of the response is different. The 4 byte response is called the Long Response. The user specifies the type of response in the following manner:

- At power-on, the unit defaults to Short Response. Remember that the CAN command emulates a power-on reset.
- The host can change the current setting by using the *ESC > n* command.

--We recommend using only the Short Response because it is simpler.--

Long Response Format: 4 (four) bytes are returned to the host as follows:

<i>Byte Number</i>	<i>Contains</i>
1	00H
2	ENQ Short Response (see above)
3	Mechanism Status, byte #1
4	Mechanism Status, byte #2

7.3 Send ACK After Processing

Host Sends: *ESC ACK* - 1BH 06H
Printer Response: 1 bytes.
Response Type: Immediate response.
Response Format: *ACK* - 06H

Usage Details:

This command is typically used to by the host to keep track of a print job's progression.

A common use would be to send a complete print job, then send an *ESC ACK* command. The host can wait until an *ACK* is received back from the printer. When this occurs, the host knows that the previous print job is complete.

Another use would be on Validation mode. The host can send the *ETB* command to set the printer into validation mode, followed by the *ESC ACK*. When a Form is finally inserted, the printer will respond with an *ACK*. The host can use this information to properly pace the prompts given on a computer screen.

7.4 Send Feature Status.

Host Sends: ESC ? *n*
Printer Response: 1 Byte, or 2 Bytes, or Multi-byte Sequence,.
Response Type: Processed.

Usage Details:

By specifying *n*, the host can obtain information on the following features:

<i>n</i>	<i>Feature Status Requested</i>
00H or 02H	Send Mechanism Status
10H ... 1FH	Read Counter #0 (through #15).
20H ... 2FH	Reset Counter #0 (through #15).
30H	Send Model ID String
32H	Send Firmware Version Number String
40H ... 6FH	Read Configuration Byte #0 (through #47). See Configuration Byte Table.
others	Reserved.

The number of bytes returned depends upon *n* in the following manner:

<i>Value of n</i>	<i>Number of Bytes returned.</i>
00H <= <i>n</i> < 30H	2
30H <= <i>n</i> < 40H	Multi-byte Sequence.
40H <= <i>n</i>	1

Two byte values are returned as MSB first and LSB last. Multi-byte Sequences are returned in this form:

STX mn data ETX

STX 02H
m LS Byte of COUNT
n MS Byte of COUNT
data data returned
ETX 03H

COUNT Number of bytes in data and ETX

More information is provided on each available feature.

Feature: 00H / 02H = Mechanism Status.

Provides bit-mapped information on the current state of the printer mechanism. Two bytes of information are returned, Byte #1 first.

Byte #1: Print-head and Ink-Cartridge

Bit	Function	Value	
		0	1
7 msb	0 - reserved		
6	0 - reserved		
5	0 - reserved		
4	Print-head jam	not jammed	jammed
3	Print-head docked	not docked	docked
2	Print-head at loading station	not loading sta.	at loading sta.
1	Ink-Cartridge empty	not empty	empty
0	Ink-Cartridge removed	installed	removed

Byte #2: Paper and Misc. Sensors

Bit	Function	Value	
		0	1
7 msb	0 - reserved		
6	Paper loaded	paper out	loaded
5	Paper Top-of-Form Mark (Reserved)	not sensed	sensed
4	Paper in Presenter (Reserved)	not in presenter	in presenter
3	Paper feed fault	OK	fault
2	0 - reserved		
1	Door #2 Sensor (Reserved)	contact closed	contact open
0	Door #1 Sensor	contact closed	contact open

Features: 10H - 1FH = Read Counters.**Features: 20H - 2FH = Reset Counters.**

These features are used to track supplies usage.

<i>n</i>	<i>Counter</i>	<i>Units</i>
18H	Cutter Usage	cuts / 256
1BH	Ink-Drops	Number of drops / 256*256
1CH	Paper Usage	Length of feed (inches)
28H	Reset Cutter Counter	
2BH	Reset Ink-Drop Counter	
2CH	Reset Paper Usage	

The Counters are reset by accessing feature numbers 20H through 2FH. No values are returned.

Features: 30H - 32H = Information Strings

These features are used to identify the printer to the host.

<i>n</i>	<i>Item</i>	<i>Returns</i>
30H	Model ID	Model ID String
32H	Firmware ID	Firmware Number and Revision
33H	Font ID	Font File Name and Revision <added to code Oct. 2002>

Features: 40H - 6FH = Configuration Bytes

These features are used to configure various options. Most of the options are for factory use.

<i>n</i>	<i>Item</i>	<i>Returns</i>
4EH	R2L Alignment	Current adjustment in dots for Journal Print. Signed value.
4FH	R2L Alignment	Current adjustment in dots for Validation Print. Signed value.
50H	MLV Prefeed	Current adjustment for prefeed steps in ML Validation.
	Calibration	Signed value.

8 Interfacing Examples

To illustrate the various modes, this section presents examples. The following type-styles are used:

Text	- Text characters to be printed
<i>ESC</i>	- Control characters in symbol form, consult table for hex values
19H	- Control characters is hex form. Only 1 byte is send.
spaces	- Ignore spacing. Included for easy of reading only.
-Notes	- Notes

Example #1: Print 1 line

This prints 1 line. *CR*

This prints 1 line and feeds 1 line. *CR LF*

Example #2: Barcode Printing. Code-39

See the examples given in the specification of the *ESC %* command.

Example #3: Print, Cut, Eject Receipt.

Receipt text, line #1. <i>CR LF</i>	- print & feed
Receipt text, line #2. <i>CR LF</i>	- print & feed
Receipt text, line #3. <i>CR LF</i>	- print & feed
Receipt text, line #4. <i>CR LF</i>	- print & feed
<i>VT</i>	- feed into present & past cutter
<i>ESC A</i>	- full cut
<i>ESC c</i>	- eject receipt

Example #4: Multi-line Validation Print-job

<i>ESC @</i>	- soft initialize
<i>ETB</i>	- enter validation mode
Validation text, line #1. <i>CR LF</i>	- print & feed
Validation text, line #2. <i>CR LF</i>	- print & feed
Validation text, line #3. <i>CR LF</i>	- print & feed
Validation text, line #4. <i>CR LF</i>	- print & feed
<i>FF</i>	- eject form

Example #5: Inquiries

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ENQ</i>		
	62H	Printer Ready, No Form, Not awaiting Form
<i>ENQ</i>		
	63H	Printer Ready, Form Inserted, Not awaiting Form
<i>ENQ</i>		
	61H	Printer Not Ready, Form Inserted, Form needs removal or adjustment

Important Note: Printer responses are bit specific. Decode by bits, not values.

Example #6: Monitoring Cut-Form Validation

When validating Forms, it is often important for the applications program to monitor and control the flow at the printer. This is typically done to coordinate prompts on a computer terminal with the validation.

Method #1: Test for Form inserted before sending data.

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ETB</i>		Prompt Operator to insert cut-form Wait for cut-form insertion
<i>ENQ</i>		
	62H	Printer Ready, No Form
<i>ENQ</i>		
	63H	Printer Ready, Form Inserted
<i>Send print data</i>		
<i>FF</i>		Eject Form

Method #2: Send Validation command, wait for completion via *ESC ACK*

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ETB</i>		Prompt Operator to insert Form
<i>ESC ACK</i>		Wait for cut-form insertion
	<i>ACK</i>	ACK response after Form inserted.
<i>Send print data</i>		
<i>FF</i>		Eject Form

Method #3: Send print job, wait until completed.

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ETB</i> <i>Send print data</i> <i>FF</i>		Prompt Operator to insert Form Eject Form command Wait for print job to complete.
<i>ENQ</i>	23H	Buffer not empty, printing in progress...
<i>---</i> <i>ENQ</i>		Continue polling...
	62H	Buffer empty, printing complete... Print job complete.

Method #4: Send print job, wait until completed.

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ETB</i> <i>Send print data</i> <i>FF</i>		Prompt Operator to insert Form Eject Form command Wait for print job to complete.
<i>ESC ACK</i>		... Printing in progress ...
	<i>ACK</i>	Print job complete
		.

Method #5: Wait until printer idle, send new print-job.

<i>Host</i>	<i>Printer</i>	<i>Meaning</i>
<i>ENQ</i>		Wait for printer idle
<i>---</i> <i>ENQ</i>	23H	Buffer not empty, command uncompleted... Continue polling...
<i>ETB</i> <i>Send print data</i> <i>FF</i>	62H	Buffer empty, prior printing complete. Prompt Operator to insert Form Eject Form command

9 Control Codes and Character Set Tables

The following table lists potential control codes and their Hex values.

Control Code Table: 00H - 1FH

Code Symbol	Ctrl Char	Hex Value	Code Symbol	Ctrl Char	Hex Value
NUL	^@	00	DLE	^P	10
SOH	^A	01	DC1	^Q	11
STX	^B	02	DC2	^R	12
ETX	^C	03	DC3	^S	13
EOT	^D	04	DC4	^T	14
ENQ	^E	05	NAK	^U	15
ACK	^F	06	SYN	^V	16
BEL	^G	07	ETB	^W	17
BS	^H	08	CAN	^X	18
HT	^I	09	EM	^Y	19
LF	^J	0A	SUB	^Z	1A
VT	^K	0B	ESC	^[1B
FF	^L	0C	FS	^\	1C
CR	^M	0D	GS	^]	1D
SO	^N	0E	RS	^^	1E
SI	^O	0F	US	^_	1F

ASCII Character Set: 20H - 7FH

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
20	sp	!	"	#	\$	%	&	'	()	*	+	,	-	.	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_
60	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	•

Code Pages Supported:

- Code Page 850

10 Associated Features & Options

10.1 Cutter

The Cutter option is not presently available on this model.

10.2 Supplies Usage Counters

The printer uses counters to account for the supplies in use. Ink dots and paper use are tracked and current status is available via ESC ?n command.

When the usage or ink or paper approaches its expected life, it may be replaced on a preventative basis. If replaced, the host should clear the usage counter.

10.3 Cash Drawer Interface

The printer has an optional interface to a cash-drawer. This option is factory installed and includes the following inputs and outputs.

<i>Item</i>	<i>Usage</i>
<i>Cash Drawer Pulse Output</i>	A 24V pulse of user specified width is provided to operate standard cash drawers.
<i>Cash Drawer Sensor</i>	A sensor is provided which can sense the state of an external switch. Typically the sensor is attached to a switch on a cash drawer. The host computer can determine if the drawer is open or closed.

Interface Connector:

Type: RJ-11 (6 pin phone-jack type)

Pin Out: See table.

<i>Pin</i>	<i>Name</i>	<i>Input/ Output</i>	<i>Usage</i>
1	GND	--	<i>Signal Ground</i>
2	+24V	Output	<i>24 Volts Power</i> <ul style="list-style-type: none"> • Max.current output during drawer pulse is 500 mA. • Do not use this signal for any other purpose. • The output is un-regulated 24 Volts, however, the output can be internally switched to an slightly lower (approximately 17V) unregulated power supply, if required.
3	n/c	--	
4	DWR_IN	Input	<i>Drawer Sensor</i> <ul style="list-style-type: none"> • Attaches to an external sensor which determines whether the cash drawer is open or closed. This condition is returned to the host via the Inquiry Command if required. • Attach switch between this pin and GND. • The signal should be driven by either a mechanical switch or an open-collector type driver. This signal is pulled up to 5 Volts internally via a 2.2KOhm resistor. Whether this signal is active high or active low depends on the application.
5	PULSE/	Output	<i>Drawer Kick Out Pulse</i> <ul style="list-style-type: none"> • An output which can be used to open cash drawers. • This is an open collector darlington type output, which can sink 500 mA maximum. If this signal drives a solenoid from the +24V supply, the impedance of the solenoid must be greater than 24 Ohms. • When the signal is active, the voltage on this pin is pulled low to about 1V with respect to GND.
6	CGND	--	<i>Chassis/Frame Ground</i>

Note: The cash drawer option requires optional firmware. Contact factory for more information.

11 Document Revision Information

<i>Revision</i>	<i>Date</i>	<i>Changes</i>
1.1	10-24-00	Initial release. Base document was IJ9W.doc for the IJ-9000.
1.2	03-26-01	Added: <ul style="list-style-type: none"> • ESC '2' 03H – Standard Bold Font command Corrected: <ul style="list-style-type: none"> • 38400 Baud, was 19200 • CAN = 18H, was 17H
1.3	12-05-01	Corrected: <ul style="list-style-type: none"> • Validation printfield = 2.67 was 3.68 and 2.75
1.4	11-25-02	Added: <ul style="list-style-type: none"> • MLV Prefeed calibration. • ESC = command. • ESC r and ESC t commands.
1.5	01-29-03	Removed: <ul style="list-style-type: none"> • Cutter and cash drawer commands. Corrected: <ul style="list-style-type: none"> • 38400 Baud, was 19200 • Weight